

▲ READ ALL INSTRUCTIONS CAREFULLY BEFORE USE Once assembled, the e-Tint® motorcycle visor insert is intended to be permanent. You may not reposition the insert once it is mounted to your helmet faceshield. Please read and follow installation instructions carefully. To view a video of these instructions visit www.e-tintproducts.com.

INSTALLATION INSTRUCTIONS

1. Choose a dry and dust free place for installation. Remove the faceshield from your helmet. Thoroughly clean and dry the inside of the faceshield per manufacturer's instructions, or with a mild detergent and water. Remove all fingerprints, grease residues, dirt, and moisture.

2. Reinstall the faceshield to your helmet. **Do not touch the inside of the faceshield or the inside surface of the visor while installing it as both must remain free of fingerprints.**

3. Remove the backing from the vinyl installation template (included in the installation guide folder). With your helmet faceshield down and fully closed, center the installation template on the outside surface of the faceshield. Align the installation template within the perimeter of the helmet portal so that it fits within the opening (Diagram 1).

4. Leaving the vinyl installation template in place, remove the faceshield from the helmet. Set it face down on a soft, clean surface (Diagram 2).

5. **Do not touch the inside surface of the insert and faceshield as any smudges or fingerprints on these surfaces will not be removable after installation.** Carefully pull away the liner from the perimeter adhesive of your e-Tint® motorcycle visor insert (Diagram 3).

6. Hold the visor insert by its outer edges and gently bend into a "U" shape. Align the cross-hairs of the visor insert with the vinyl installation template (Diagram 4).

7. When correctly positioned, gently apply the visor insert to your faceshield. Mount the visor insert by applying firm pressure along the adhesive gasket, moving from the center outwards (Diagram 5). A small airspace between the interior surfaces of the faceshield and insert will be expected. **NOTE: Avoid repositioning the insert after making contact with the faceshield; this will reduce the performance of the adhesive.**

8. Carefully remove the installation template from the back surface of the motorcycle visor insert and discard (Diagram 6).

9. Remove the vinyl installation template from the outside of the faceshield and discard.

10. Plug the wire from the electronics module into the harness attached to the tab of the visor insert (Diagram 7). Wrap the wire under the faceshield.

11. Remove the liner from the back of the electronics module. Horizontally mount the module on a flat section on the front of the faceshield (Diagram 8). You may also prefer to position the

module vertically (Diagram 8a). **NOTE: Avoid repositioning the electronics module after making contact with the faceshield; this will reduce the performance of the adhesive.**

12. Allow the adhesive of the visor insert and electronics module to set for 1 hour before reinstalling the faceshield to your helmet. (While the adhesive sets, you may charge the electronics module by using the supplied micro USB. The LED on the back of the module will turn off when fully charged) (Diagram 9).

13. Reinstall the faceshield to your helmet and ENJOY!

