E-TINT® EYEWEAR • OWNER'S MANUAL

Please follow these care and usage instructions to ensure optimal performance from your eyewear.



DIRECTIONS OF USE

GLOSSARY OF TERMS ACTIVATE: Turn on; tint | DEACTIVATE: Turn off; clear

e-Tint® electronic-tinting eyewear changes instantly between two levels of tint (on or off) by either a quick press of the button or automatically via the built-in light sensor. These tint levels are fixed and cannot be changed by the user. The eyewear comes pre-programmed with a standard setting for automatic mode. You can adjust the light sensitivity if you determine that it does not automatically turn on or off to your liking (see "Adjust Light Sensitivity" below).

TO OPERATE IN MANUAL MODE: Quickly press and release the button to activate or deactivate the tint of the eyewear.

TO OPERATE IN HANDS-FREE (AUTOMATIC) MODE: The eyewear can automatically tint in the presence of an activating light. To switch the system to automatic mode, simply press and hold the button for approximately three (3) seconds. The lens will flash to indicate it has been switched into automatic mode. Release the button. The eyewear is now set for hands-free (automatic) use.

TO EXIT HANDS-FREE (AUTO) MODE, AND ENTER MANUAL MODE: Press the button once to go back to manual mode. Note: The lens will turn clear upon exiting automatic mode.

TO ADJUST LIGHT SENSITIVITY: First, switch the eyewear to automatic mode. Choose an ambient area of light that would be similar to where you want the eyewear to activate. Stand in your desired lighting condition. Press & hold the button for about four (4) seconds. After four seconds, the lens will flash to indicate the system has re-calibrated its sensor to your desired setting. Light that is as bright as, or brighter than, your selected ambient lighting will now trigger the sensor. The electronics will store this custom setting until it is re-adjusted or reset to its factory setting. **NOTE: Be sure to keep the area around the light sensor clear and open to the light source.** If your finger is covering the light sensor during the adjustment, the eyewear will stay activated most of the time and only switch when it is very dark. DO NOT attempt to change the light sensitivity when moving.

FOR A FACTORY RESET: A factory reset can be performed in either manual or automatic mode. Press and hold the button for approximately six (6) seconds. The lens will cycle through (2) sets of flashing. After the second set of flashing, the eyewear will be restored to its original factory settings.

WARNING! DO NOT USE tinted lenses in the dark. DO NOT USE if lenses are scratched. IT IS YOUR RESPONSIBILITY TO DETERMINE THE SUITABILITY OF THIS PRODUCT FOR ITS INTENDED USE. IF AT ANY TIME YOUR EYEWEAR IS NOT PERFORMING PROPERLY, DISCONTINUE USE OF THE EYEWEAR AT ONCE. NOT RECOMMENDED FOR USE OR STORAGE IN TEMPERATURES BELOW -10°C (14°f) OR ABOVE 45°C (113°F).

CHARGING: Connect the supplied USB cable to eyewear and charge with a wall adapter or computer. The lens will tint when charging and turn off when fully charged. A completely depleted battery will take up to two (2) hours to fully charge.

LONG-TERM STORAGE: If the eyewear will be stored for a prolonged period of time, it is recommended to full charge the battery once per year. Doing so will prolong and protect the capacity of the battery.

WARNING! IF EYEWEAR OR USB CABLE HAVE BEEN EXPOSED TO EXCESSIVE SWEAT OR MOISTURE, ALLOW UNIT TO DRY (APPROX. 8 HRS.) BEFORE CHARGING. DO NOT STORE EYEWEAR CONNECTED TO A CHARGING SOURCE FOR AN EXTENDED PERIOD OF TIME.

COMFORT & FIT: This e-Tint® spectacle is equipped with 360° bendable temple arms to allow for a comfortable and customized fit.

CLEANING & CARE: Clean with warm water, mild detergent, and a soft cloth. For stubborn residues clean with a household glass cleaner. DO NOT use cleaners which contain moisturizers, abrasives, strong acids, or caustics. DO NOT immerse the spectacle in liquids. **DO NOT leave or store eyewear in excessive heat when not in use.**

RETURN POLICY

For warranty/repair service, or to return any new, unopened product for a full refund or exchange (within 30 days of purchase), please contact Customer Support at support@e-tintproducts.com or visit www.e-tintproducts.com for a Return Merchandise Authorization (RMA) number and specific shipping instructions. Products returned for a full refund must be in new condition and in original packaging (including all accessories), and returned to us within 30 calendar days of the issuance of the RMA. A 20% restocking fee may be charged for any accessories or components missing from the returned product. A purchase receipt MUST be provided with the return of any product. Products returned without an RMA will not be eligible for a refund or exchange. The shipping and duty charges for returning a product are the customer's responsibility. The following information is required for all returns: **LOT NO. & SKU NO.** found on the UPC label (on the retail box), **origial purchase receipt, and customer information.**

LIMITED WARRANTY

All e-Tint® products are warranted to the original purchaser for six (6) months from the date of purchase against manufacturing defects in materials and workmanship. Upon receiving returned product(s) that e-Tint determines to be defective, we will repair or replace the product at our option. Please contact Customer Support at support@e-tintproducts.com for warranty service.
This warranty does not affect the legal rights of customers under applicable state or national laws governing the sales of consumer goods.

EXCLUSIONS
The Return Policy and Limited Warranty does not apply to: (a) normal wear and tear, including scratched lenses; (b) water damage; (c) damage due to neglect, abuse, misuse, or mishandling; (d) damage caused by improper storage or improper maintenance; (e) damage caused by use of chemicals or improper cleaning; (f) damage due to accidents or acts of nature; and (g) battery damage from improper use; (h) damage resulting from alterations, changes, or repairs not authorized in writing by e-Tint.

Online Auction Purchases: Products purchased through online auctions (other than our primary websites or Authorized Dealers) are not eligible for warranty coverage. Online auction confirmations are not accepted for warranty verification. EXCEPT AS SET FORTH IN THE LIMITED WARRANTY, ALL E-TINT® PRODUCTS ARE PROVIDED ON AN "AS IS" BASIS. TO THE EXTENT PERMITTED BY APPLICABLE LAW, ALL OTHER WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, ARE EXPRESSLY DISCLAIMED.

This product protected by patents in the U.S. and elsewhere. For details, visit at: e-tintproducts.com/intellectual property

COPYRIGHT © 2026 e-TINT